

Bracket Shelf

INSTALLATION INSTRUCTIONS



SAFETY INFORMATION

Follow these instructions carefully. Do not place any more than 5kg of total weight on a shelf at any one time. It is the responsibility of the customer to ensure the shelf is adequately fastened to the wall and that the wall or plaster is in a condition capable of safely securing the shelf. If this shelf is not adequately fastened to the wall, or the wall or plaster is not adequate, the shelf may fall and cause serious injury.





VIEW VIDEO

Click the button above to view a short installation video on our
YouTube Channel @jemmervaledesigns

GET ORGANISED

WHAT'S INCLUDED

bracket shelf

2 x wall brackets

4 x white plaster wall screws

4 x large black screws

2 x small black screws

rod and sash cord (if purchased)

WHAT YOU NEED

electric drill & 3mm drill bit

phillips head screwdriver

pencil

measuring tape

stud finder

level (optional)

STEP 1

Find ideal position for your shelf by holding your shelf against the wall. Place a pencil mark on the wall at one end of the shelf.



STEP 2

Measure 15cm towards the middle of the shelf from your pencil mark.

We recommend the position of the brackets to be 60cm apart, which is approx. 15cm from the end of each shelf to the top screw in the bracket.



STEP 3

Before screwing in the plaster wall screw at this location, use your stud finder to ensure that there is no stud at that point. If there is a stud you will need to move the position of your shelf slightly, or use a longer screw (8G x 50mm) without the plaster screw.

STEP 4

If there is no stud, screw in the plaster wall screw with your screw driver or electric drill on a low speed setting.



STEP 5

Attach the first bracket to your wall by placing a large black screw through the top hole in the bracket and screw it into the plaster screw.

STEP 6

Using your spirit level to ensure the bracket is straight up and down, place a second long black screw into the bottom hole and press it firmly into the plaster to mark its location and then remove the screw.



STEP 7

Undo the top screw 1 or 2 turns to enable you to move the bracket enough to expose the mark you just made on the wall. Screw in the second plaster wall screw at the mark on the wall with your screwdriver or electric drill on a low speed setting.



STEP 8

Re-position the bracket and screw in the second long black screw into the plaster screw. Tighten the top screw again.



STEP 9

Place a mark 60cm from the screw of the first bracket for the location of the second bracket. Ensure that the mark is at the same height of the top screw in the first bracket using your spirit level or tape measure.

STEP 10

Before screwing in the plaster wall screw, use your stud finder to ensure that there is no stud at that location. If there is a stud you will need to move the bracket for your shelf or use a longer screw (8G x 50mm) without the plaster screw. If there is no stud, screw in the plaster screw with your screwdriver or electric drill on a low speed setting.

STEP 11

Attach the second bracket to your wall by placing a large black screw through the top hole in the bracket and screw it into the plaster screw.

STEP 12

Using your spirit level to ensure the bracket is straight up and down, place a second long black screw into the bottom hole and press it firmly into the plaster to mark its location and then remove the screw.



STEP 13

Undo the top screw 1 or 2 turns to enable you to move the bracket enough to expose the mark you just made on the wall. Screw in the second plaster wall screw at the mark on the wall with your screwdriver or electric drill on a low speed setting.



STEP 14

Re-position the bracket and screw in the second long black screw into the plaster screw. Tighten the top screw again.



STEP 15

Now you need to attach the shelf to the brackets. To do this you will need to place the shelf on the brackets and ensure that it is centred on the brackets using a tape measure.



STEP 16

While holding the shelf on the brackets firmly, drill a pilot hole with your 3mm drill bit, through each of the holes that connect the bracket to the shelf being very careful to not go through the top of the shelf.

STEP 17

Screw the shelf onto the brackets using the small black screws.



STEP 18 (OPTIONAL)

If you purchased the rod follow the following steps; tie a knot on one end of each of the pieces of cord. Place each piece of cord down through the top of the holes on the shelf. (Taping the end of the cord can assist with getting it through the hole.



STEP 19 (OPTIONAL)

Secure the rod to the cords at your desired height using a suitable knot. Ensure that there is adequate cord so that the knot does not come undone, then cut off excess cord.

We recommend a clove hitch knot (click [here](#) to see a video of how to tie one).



STEP 20

If you have purchased a double shelf and rod set, then you will need to repeat the previous instructions to install your second shelf. And then style away!



PLEASE NOTE

The fixings provided are intended for mounting the shelf into gyprock/plaster/drywall. We recommend no greater than 5kg of weight added to the shelf. If you are mounting the shelf into studs in the wall additional fixings from your local hardware store will need to be bought suitable for your situation.



BRACKET SHELF - INSTALLATION INSTRUCTIONS



MOODBOARD

A wooden clothing rack with a light-colored corduroy hat and several sweaters hanging on it. The rack is made of light-colored wood and has a horizontal bar with several white hangers. The background is a light-colored wall with a subtle pattern.

LEAVE REVIEW

**We hope you love your Jemmervale Designs shelf!
If you have time, please leave us a review.**

BRACKET SHELF - INSTALLATION INSTRUCTIONS



CONTACT

E-mail

hello@jemmervaledesigns.com.au

Website

jemmervaledesigns.com.au

Phone

0400 981 250

Address

475 Verney Road, Shepparton VIC, Australia